


BCDCMB-105

Mounting Bracket for Selected REDARC BCDC Battery Chargers

SUITABLE FOR TOYOTA HILUX

(10/2015-PRESENT)





BCDC Alpha Mounting Bracket

Suitable for TOYOTA Hilux

(10/2015-PRESENT)

The REDARC **BCDCMB-105** Mounting Bracket is designed to install your BCDC Classic/BCDC Alpha Battery Charger close to an auxiliary battery mounted in the engine bay. Do not use if the battery is located elsewhere.

For maximum performance, mount your BCDC Classic/BCDC Alpha in the cool airflow at the front of your vehicle, away from high temperature areas.

The BCDC Alpha Mounting Bracket is constructed from durable stainless steel and has been designed to fit existing mounting points in your vehicle for ease of installation.

*NOTE: The BCDC Alpha Mounting Brackets are only for engine bay designed Battery Chargers. DO NOT use the Mounting Bracket to install a BCDC Core Battery Charger (BCDCN1225, BCDCN1240).

WARNINGS AND SAFETY INFORMATION

SAVE THESE INSTRUCTIONS - this manual contains important safety instructions.

Do not install the BCDC Alpha Mounting Bracket unless you have read and understood this manual.

REDARC recommends to review your vehicle to ensure this kit suits your vehicle's make and specifications.

REDARC recommends that the BCDC Alpha Mounting Brackets be installed by a suitably qualified person. It is the installers responsibility to ensure their installation complies with any applicable legal and regulatory requirements.

Disclaimer: REDARC accepts no liability for any injury, loss or property damage which may occur from the improper or unsafe installation or use of its products.

SAFETY MESSAGE CONVENTIONS

Safety messages in this manual include a signal word to indicate the level of the hazard as follows:

Indicates a potentially hazardous situation which could result in death or serious injury to the operator or to bystanders.

A CAUTION

A WARNING

Indicates a potentially hazardous situation which may result in moderate or minor injury to the operator or to bystanders.

NOTICE

Indicates a situation that may cause equipment damage.

A WARNING

 Do not operate around the engine bay with the engine operating. Ensure the vehicle is OFF before mounting Battery Charger assembly.

A CAUTION

• Use Personal Protective Equipment (PPE). Wear appropriate clothing as well as eye protection when operating power tools.




• Take care when working in and around engine bay to avoid punch points, sharp edges and hot surfaces.

NOTICE

- Removing existing vehicle fixings may expose bare metal, resulting in rust. Retouch any
 exposed metal with rust inhibitor if it is not an earth connection.
- Damage to cabling can cause failure of the Battery Charger and vehicle electrical systems. Ensure wiring is clear of sharp edges and moving parts.

BCDC ALPHA MOUNTING BRACKET PARTS



- **1. Mounting Bracket** Supplied with 1 bracket
- 2. M6 × 12 mm Pan Head Bolt Supplied with 4 bolts
- 3. M6 × 20 mm Pan Head Bolt Supplied with 4 bolts
- 4. M6 Nyloc Locking Nut Supplied with 4 nuts

Supplied with 1 nut 7. M8 Flat Washer

- Supplied with 3 washers
- 8. M8 Spring Washer Supplied with 1 washer
- **9. Installation Template** Supplied with 1 template

5. M8 × 20 Hex Head Bolt Supplied with 2 bolts

RECOMMENDED TOOLS

The tools listed below are typically sufficient to complete the installation, however, some specific models may require more specialised tools.

- Metric Socket set (at least 10 mm and 12 mm socket) with extension bars.
- Metric Spanner 10 mm, 12 mm and 13 mm.
- Medium (#3) Phillips-Head Screwdriver.

ASSEMBLY

ASSEMBLE THE MOUNTING BRACKET


The BCDC Alpha Mounting Bracket must be bolted and fitted to the Battery Charger before mounting to the vehicle. Do not install the BCDC Alpha Mounting Bracket to the vehicle first.

BCDC Classic Battery Charger

If mounting a BCDC Classic Battery Charger, use the supplied $M6 \times 12 \text{ mm}$ Pan Head Bolts and M6 Nyloc Locking Nuts to secure the Battery Charger to the Mounting Bracket (see Figure 1).

BCDC Alpha Battery Charger


If mounting a BCDC Alpha Battery Charger, use the supplied M6 × 20 mm Pan Head Bolts and M6 Nyloc Locking Nuts to secure the Battery Charger to the Mounting Bracket (see Figure 2).



PRIOR TO INSTALLATION

LOCATION OF INSTALLATION


The assembled Mounting Bracket will be installed centrally (see Figure 3).




REMOVE COVER PANEL

Remove the cover panel by popping the 8 clips out as shown in Figure 4. Lift the cover panel clear and away from the vehicle.

Retain the clips for re-fitting the cover panel after installing Mounting Bracket assembly.





COMPLETE BATTERY CHARGER WIRING

NOTICE: Damage to cabling can cause failure to the Battery Charger and the vehicle's electrical system. Ensure wiring is clear of sharp edges, moving parts and has enough slack to allow for flexing.

Fit the Battery Charger with the wiring connected to the bracket before mounting in the vehicle. It is difficult to access the Battery Charger once the bracket is installed.


Complete the required wiring in accordance with your Battery Charger's instruction manual.

INSTALLATION

A CAUTION: Take care when working in and around engine bay to avoid punch points, sharp edges and hot surfaces.

NOTICE: Removing existing vehicle fixings may expose sharp surfaces and bare metal resulting in rust. Retouch any exposed metal with rust inhibitor if it is not an earth connection.

Remove the side bolt attached to the bonnet catch, this bolt will be used to secure the top mounting point. Position the Mounting Bracket assembly so the top mounting point is inline with the bonnet catch bolt (see Figure 5).




Secure the top mounting point by re-fitting the bolt.

SECURING MOUNTING BRACKET TO VEHICLE

To secure the two low mounting points of the Mounting Bracket assembly, refer to Figure 6 and adhere to the following steps:

- 1. Fit the supplied M8 × 20 mm Hex Head Bolt with a Flat Washer and Nyloc Locking Nut to the grille support mount.
- 2. Fit the other M8 \times 20 mm Hex Head Bolt with a Spring Washer and Flat Washer to the support bracket with captive nut.
- 3. Tighten both Hex Head Bolts to 5 Nm (3.7 lbf-ft) to secure the Mounting Bracket assembly.
- 4. Ensure bonnet catch bolt is tightened correctly to the vehicle manufacturer's torque specifications.




CUTTING AN INSPECTION HOLE IN THE COVER PANEL

A CAUTION: Use Personal Protective Equipment (PPE). Wear appropriate clothing as well as eye protection when operating power tools.




Before re-fitting the cover panel back to the vehicle, create an inspection hole to view the status of your Battery Charger. Follow the instructions below, ensuring you cut the inspection hole away from the vehicle.

- 1. Refer to cut-line area shown in Figure 7.
- 2. Mark the area and cut neatly to create the inspection window for your Battery Charger. REDARC recommend using a centre punch/scribe and a small, serrated blade or reciprocating saw for cutting the cover; and de-burr rough edges.




FITTING THE COVER PANEL

Check the inspection hole for alignment with the Battery Charger's front panel and if required remove the cover panel from the vehicle to trim excess plastic. Re-fit the cover panel and secure with the clips removed during cover removal. These clips are secured when the centres are flush with the outer edge of the clip.



COMPLETED INSTALLATION

Once the cover panel is fitted back to the vehicle, the installation is complete.



MAINTENANCE

A CAUTION: Ensure the area around the Battery Charger is clean and clear of debris. Any debris not removed will impair the performance of the unit and may cause a fire hazard.

NOTE: Regularly check your vehicle to avoid potential damage to the Battery Charger, your vehicle and batteries (both auxiliary and starter).

WARRANTY

LIMITED WARRANTY

For full warranty terms and conditions, visit the Warranty page of the REDARC website. **www.redarcelectronics.com/warranty**

Australia, New Zealand, UK & Europe

REDARC Electronics Pty Ltd 23 Brodie Road (North), Lonsdale SA 5160 Australia

North America

REDARC Corporation c/o Shallco, Inc. 308 Component Dr. Smithfield, NC 27577 USA

Australia	+61 8 8322 4848	USA	+1 (704) 247-5150
New Zealand	+64 9 222 1024	Canada	+1 (604) 260-5512
UK & Europe	+44 (0)20 3930 8109	Mexico	+52 (558) 526-2898

IMPORTER CONTACT INFORMATION

UK

Ozparts UK Ltd 1 Prospect Place Pride Park DE24 8HG, Derby UK

Europe

Ozparts Sp. z o. o. Sp. kom. Slowackiego 32/5 87–100 Torun Poland

For written request please email power@redarcelectronics.eu

Design and specifications are subject to change without notice. | Copyright © REDARC Electronics Pty Ltd. All rights reserved. REDARC®, THE POWER OF REDARC® and Alpha® are trademarks of REDARC Electronics Pty Ltd.

Tech Support 1300 REDARC (1300-733-272)

Australia +61 8 8322 4848

New Zealand +64 9 222 1024

UK & Europe +44 (0)20 3930 8109

USA +1 (704) 247-5150

Canada +1 (604) 260-5512

Mexico +52 (558) 526-2898

redarcelectronics.com

